

PythonWin Instalation Guide

30/08/07



1.1 Python installation

If you are having problems with version of PythonWin 1.5.2+ that we advise all our clients to use in *Python Easy Script* document please try with downloading the latest PythonWin (currently PythonWin ver. 2.5).

Software will function correctly with the PC running Windows 2000 or XP.

In order to install PythonWin and Telit built in modules correctly please proceed in the following way:

1) on the Python's official site: <http://www.python.org/download/> choose PythonWin 2.5 standard release and follow the download instructions in order to install it on your PC

2) install file pywin32-210.win32-py2.5.exe which you can find on the following link
http://sourceforge.net/project/showfiles.php?group_id=78018&package_id=79063&release_id=449591

3) install file pyserial-2.2.win32.exe which you can find on the following link
http://sourceforge.net/project/showfiles.php?group_id=46487&package_id=39324

4) our technical assistance team will provide you Telit built in libraries (MDM.py, MOD.py, SER.py and GPIO.py) and file Choice.exe (needed to set the serial port used for simulation by MDM and SER)

5) copy the Telit libraries in the folder Lib under the same directory where PythonWin is installed (es: C:\Program Files\Python25\Lib)

6) copy the file Choice.exe under the main root of PythonWin directory (es: C:\Program Files\Python25) and run it before you start using PythonWin for simulation

Please do not hesitate to contact us for any further questions on the e-mail: ts-modules@telit.com

